



*CLASSIC*<sup>®</sup> *SERIES* **MINI REFLEX SIGHT**  
**MANUAL**

## **THANK YOU FOR CHOOSING THIS PRIMARY ARMS OPTIC**

If you have any questions about your new optic or any of our other products, visit us at [www.primaryarmsoptics.com](http://www.primaryarmsoptics.com), email us at [info@primaryarmsoptics.com](mailto:info@primaryarmsoptics.com), or give us a call toll-free at 855-774-2767. The customer service team at our headquarters in Houston, Texas will respond promptly.


If you have any problems with a Primary Arms Optics product, we urge you to contact us immediately and let our customer service professionals handle the situation for you. There is no need to return your optic to the retailer.

\*View back cover for lifetime warranty information.

## TABLE OF CONTENTS

Page 4	Introducing: Primary Arms Classic Series Micro Reflex Sight
Page 5	Achieving a Clear Reticle Picture <b>PLEASE READ THIS FIRST</b>
Page 6	How to Set Reticle Illumination
Page 6	Zeroing
Page 8	Mounting Options
Page 8	Dot Size
Page 8	Features
Page 9	Specifications
Page 10	Lens Care
Page 11	Four Rules Of Firearms Safety

## CLASSIC SERIES MINI REFLEX SIGHT



## HOW TO ACHIEVE A CLEAR RETICLE PICTURE

If you wear prescription glasses or contact lenses, make sure to put them on before looking through the sight. To achieve a clear, crisp dot, look through the sight and focus on the target, not the dot. Shoot with both eyes open! It can also be

helpful to turn the dot's brightness down a bit, until the dot can just be seen clearly contrasted against the background.

## HOW TO SET RETICLE ILLUMINATION

There are two buttons on the optic's left side. The forward button is marked with an up arrow, and the rear button is marked with a down arrow.

To turn the optic on, press either button and hold it for three seconds. This activates the reticle.

To increase the reticle brightness, tap the 'up' button.

To decrease reticle brightness, tap the 'down' button.

To turn the optic off, press BOTH buttons and hold for three seconds. This deactivates the reticle.

NOTE: If the reticle does not appear, you may need to replace the battery. To do this, unscrew the optic and remove it from its mounting position. Remove the old battery and insert a new CR2032 battery in its place. You may then reinstall the optic on your firearm or mount.

## ZEROING

The optic is delivered in a centered position. Normally, this means that only small adjustments are necessary, providing that the

base is properly aligned. If you have a red dot magnifier, sight in without using the magnifier. Work your way to “zero” by adjusting each turret in small increments.

a. To move the point of impact to the right, turn the windage adjustment screw clockwise.

b. To move the point of impact to the left, turn the windage adjustment screw counter clockwise.

c. To move the point of impact up, turn the elevation adjustment screw clockwise

d. To move the point of impact down, turn the elevation adjustment screw counter clockwise.

The total adjustment range for both windage and elevation is 60 MOA. If you suddenly encounter resistance, do NOT try to force the screw further, this can break the mechanism and render the sight unable to zero. Confirm zero by firing at least three shots at a zeroing target. After initial firing, check that the optic and mount are secure on your firearm. Check your impact points on the target to confirm accuracy and repeat until you are satisfied that the point of aim and the point of impact coincide at your desired range.

## **MOUNTING OPTIONS**

The Classic Series Full-Sized Reflex Sight is designed to work with RMR-compatible Footprint.

## **DOT SIZE**

The Classic Series Full-Sized Reflex Sight features a 3 MOA dot, meaning that the dot itself appears to cover roughly 3 inches of target at 100 yards. The 3 MOA dot offers an excellent compromise of both speed and accuracy.

## **FEATURES**

- 10 Brightness Settings
- Bright LED with Lowlight and Daytime Settings
- Up to 40,000-hour Battery Life at Medium Settings
- 12hr auto battery shut off
- RMR Footprint
- 24x17mm Clear Aperture in a Compact and Light Weight Design
- Tough 6061 Aluminum Alloy Housing
- Multi-Coated Lens
- Backed by Primary Arms Optics Lifetime Warranty



## SPECIFICATIONS

Objective Lens Diameter: 24x17mm	Total Elevation Adjustment: ≥ 60 MOA	Illumination Settings: 10 Settings
Length: 1.78 in.	Total Windage Adjustment: ≥ 60 MOA	Battery Life: 41k Hours at Medium Setting
Weight: .98 oz	Lifetime Warranty	Battery: 3v CR 2032

*Specifications may vary and are subject to change without notice.*

## **REMEMBER: THE FOUR RULES OF FIREARMS SAFETY**

1. Treat every firearm as if it were loaded.
2. Never let your muzzle cover anything you are not willing to destroy.
3. Keep your finger off the trigger until your sights are on target.
4. Be sure of your target and what is behind.

## LENS CARE

Please do not use any organic solvent such as alcohol or acetone on your optic. First, blow dust or any foreign objects off of the lens. Then, use a soft cotton or microfiber lens

cloth to clean any fingerprints or smears off the lens. Alternatively, you may use a piece of professional lens paper for further cleaning, if necessary.



**WARNING:** Always ensure your firearm is unloaded (chamber empty and magazine removed) before installing optics or accessories.



**WARNING:** Improper installation of firearm parts or accessories may result in death or serious personal injury. If you are not properly trained in the installation of these parts, have them installed by a gunsmith or armorer.

# **WARNING**

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **INTERNAL CHEMICAL BURNS** in as little as **2 HOURS**.
- **KEEP** new and used batteries **OUT OF REACH OF CHILDREN**.
- **SEEK IMMEDIATE MEDICAL ATTENTION** if a battery is suspected to be swallowed or inserted inside any part of the body.



- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- Ensure the batteries are installed correctly according to polarity (+ and -).
- Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries. Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
- Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

## NOTES:

---

---

---

---

---

---

---

---

---

---

**NOTES:**

---

---

---

---

---

---

---

---

---

---



## LIFETIME WARRANTY

Your Primary Arms Classic Series Micro Reflex Sight is covered by the Primary Arms Lifetime Warranty. If a defect due to materials or workmanship, or even normal wear and tear has caused your product to malfunction, Primary Arms will either repair or replace your product. You can find more details about our lifetime warranty at [www.primaryarmsoptics.com](http://www.primaryarmsoptics.com).

Email: [info@primaryarmsoptics.com](mailto:info@primaryarmsoptics.com)  
Toll-free at 855-774-2767  
[www.primaryarmsoptics.com](http://www.primaryarmsoptics.com)



SCAN HERE for  
more information  
on these optics.

©Copyright 2024 PRIMARY ARMS, LLC  
is a registered trademark of PRIMARY ARMS, LLC

For Patent Information go to <https://goo.gl/2z62aS>